



INSTALLATION INSTRUCTIONS
WINDSHIELD MIRROR RELOCATION BRACKET
2003 TJ WRANGLER – 1502

Congratulations on your purchase of Warrior Products Windshield Mirror Relocation Bracket for your Jeep. Be sure to open the box and examine the contents before beginning. Read these instructions completely before starting your installation.

1. The Warrior Mirror Relocation Bracket attaches to the side of your windshield, on the lower part of the windshield hinge.
2. Remove the two bolts on the side of the windshield hinge. Remove one bolt at a time, CAREFULLY, to avoid dropping backing nuts located inside the framework.
3. Mount the Warrior Mirror Relocation Bracket using the two (2) tapered stainless steel bolts provided for each side.
4. Remove your stock mirror from your door by unscrewing the three bolts in the door.
5. Mount the mirror to the Relocation Bracket using the ¼” bolts and nuts provided.
6. When finished, be sure to go back and check the tightness of all bolts.

.....

“Your Knight in Shining Armor!”