



Protecting Your Adventure Lifestyle

SUBJECT: INSTALLATION INSTRUCTIONS: 3810 FJ Cruiser Drop-In Cargo Basket



1. Begin by bolting two clamps to the lower tube on the front of the FJ factory rack. To locate these in the proper place, we will reference the vertical tubes between the lower and upper tubes of the factory rack. The front most clamps will bolt on just in front of the front-most vertical tube. 1" long bolts with washers on each side of the plates will hold the clamps together (as shown in photo). Set the brackets parallel to each other and tighten the bolts and nuts.
2. Locate the rear clamps by measurement. From the inside edge of the brackets, set your spread at 26". Set them parallel to each other and tighten bolts/nuts.
3. Set your Cargo Basket onto the brackets. Align the holes in the rack's cross tubes with the slotted holes in your clamp brackets. Use the 2" bolts with washers on each side to secure the basket to the brackets. Adjust clamps as needed for the best alignment.
4. Tighten all bolts and nuts to secure rack into place and complete installation.