



Protecting Your Adventure Lifestyle

---

# **SPRING OVER CONVERSION KIT**

## **INSTALLATION INSTRUCTIONS**

### **WAR 4600, 4605, 4610, 4615**

---

YOUR KIT SHOULD CONTAIN THE FOLLOWING PARTS:

- 2 UNIVERSAL SHOCK MOUNTS**
- 2 SPRING PERCHES**
- 2 P-19 SHOCKBOLTS**
- 2 UNIVERSAL U-BOLT PLATES**
- 2 COUPLER NUTS**

Installation Instructions are **not** provided due to the multitude of variables that come into play when performing a spring over conversion. If you are not a qualified mechanic, or do not have access to necessary expertise, you should not attempt this conversion. You may need the assistance of your local 4X4 installer or service center.

**QUALITY** • **INTEGRITY** • **INNOVATION** • **SERVICE**

Learn more about performance suspension parts we have.