

INSTALLATION GUIDE

Rock Guards



Included Hardware:

(24) 1/4" Bolts
(24) 1/4" Spacers

Tread plate hardware:

1/4-20 x 3/4" button head bolts
1/4-20 Nylock Nuts

Tools:

3/4" wrench and socket

Skill Level:

1/5 Stars

Disclaimer

**Expedition One is not responsible for any damages to vehicle.
We always recommend professional assistance when installing our
vehicle products.**

Rock Guard Install

First, take the button head bolts and nylock nuts provided for tread plate and secure to the rock guard.

Using a 5/32" or 4mm allen and 7/16 combination wrench, tighten down tread plate to rock guard. See Fig 1B & 1C for reference photos.

*NOTE - We recommend placing each slider on the ground next to the vehicle where it will be mounted so that you have the Expedition Logo mountain facing the correct way towards the vehicle.

For the corner holes, you might need to use the open end side of the wrench to fit underneath and tighten.

FIG 1A



FIG 1B



FIG 1C



Determine which rock guard is for drivers and passenger side. The Expedition One logo is always facing towards the vehicle which is on the frame.

FIG 2A



FIG 2B

Have two people hold the rock guard into position and a 3rd person tighten down with bolts provided but keep loose.



FIG 2C

Ensure sliders are level and in the position you want them in, then tighten down all bolts.

Your all done!

If you have any questions or feedback, please email us at info@expeditionone.biz

