



Protecting Your Adventure Lifestyle

Warrior Products, Inc.  
16850 SW Upper Boones Ferry Rd  
Ste. A  
Durham, OR 97224  
Phone (888) 220-6861  
Fax (503) 692-0364  
customerservice@warriorproducts.com

---

# **CHEROKEE BUMPER**

## **INSTALLATION INSTRUCTIONS**

### **560 SERIES**

#### **Phase 1: Bumper Removal**

1. Start by unbolting your bumper on each side. There are 3 bolts in a triangular pattern that hold the bumper in place. Use a 15mm wrench or socket to remove them. If you have factory tow hooks, there will be an additional TORX head bolt further back on the frame rail holding the brackets in place, as well as a bracket on the bottom side of the frame rail.
2. The bumper should now be loose. On the passenger side, there should be a plastic vacuum canister bolted to the bumper from the bottom. Remove the bolts and pull the bumper off of the Jeep. The canister can hang loose while you install your bumper.

#### **Phase 2: Bumper Installation**

1. Slide your factory bumper, or new aftermarket bumper into place
2. Using the 3 bolts removed in Phase 1; attach the bumper to the vehicle. Thread all 6 bolts before tightening any of them. Be sure to align the bumper so it is sitting straight on the vehicle as there is some play in the holes.
3. The last part of the installation is to re-attach your vacuum canister. You can either drill holes in the bumper to hold it, or many people choose to relocate it into the engine bay.

Installation is completed. Visit [www.warriorproducts.com](http://www.warriorproducts.com) to see more of our Jeep Cherokee Accessories.

If you need further assistance installing your product, please contact us by email at [customerservice@warriorproducts.com](mailto:customerservice@warriorproducts.com) or call us at (888) 220-6861.

## **THANK YOU FOR PURCHASING WARRIOR PRODUCTS**