



---

**SUBJECT:** [Winch Mounts & Stinger Winch Mount](#) Installation Instructions

**IMPORTANT:** Hardware is not included in this kit. If you choose to not re-use the factory hardware, you can purchase new Grade 8 hardware at any hardware store.

## **INSTALLATION**

1. These winch mounts are designed to bolt over factory bumpers, and our Rock Crawler and Standard Steel Bumpers. It will work with any flat topped bumper that mounts to factory locations.
2. To begin installation, remove the top bolts holding the bumper and any tow hooks in place. The lower bolts do not need to be removed.
3. Bolt the winch plate into place over the bumper, with no winch in the plate.
4. You will now notice that two of the four winch mounting holes overlap the bumper. Mark and drill these holes into the bumper so that bolts can pass through the plate and the bumper.
5. Remove the winch mount, and unbolt and remove the bumper.
6. Assemble your fairlead or hawse to the winch mount using the hardware supplied with your winch.
7. Assemble your winch, plate, and bumper together. Use the hardware supplied with your winch. Do not forget to feed your winch cable through your fairlead/hawse as you set the winch into place.
8. With the winch, bumper, and winch mount all assembled as one piece, you can now bolt the entire assembly onto your Jeep®.
9. Finish this part of the installation by ensuring that all of your bolts are tight.
10. You can now proceed to installing your winch wiring and hook. Consult the documentation supplied with your winch to complete these steps.