



Protecting Your Adventure Lifestyle

UNIVERSAL LIGHT BRACKETS

59001, 59003, 59004, 59005

Warrior Universal Light Brackets are designed to be installed onto any appropriately sized round tubing. This may include cargo racks, brush guards, or any other products using round tubing.

1. Be sure that any bare metal surfaces are repainted prior to installation, if needed, to prevent rust.
2. Place the brackets onto the tubing and assemble by placing the bottom portion of the “clam shell” on the backside of the tubing and inserting bolts through the pre-drilled holes. Place the lock washer and nut on the ends of the bolts, once inserted through the two halves of the bracket, and tighten loosely.
3. Position the brackets where desired on the tubing and tighten the bolts.

QUALITY



INTEGRITY



INNOVATION



SERVICE

LEARN MORE ABOUT OFF-ROAD LIGHTS OUR WEBSITE.