



AR Series Bull Bar

FITMENTS

2005-2021 Nissan Frontier
2005-2007 Nissan Pathfinder
2005-2015 Nissan Xterra

**STOP - Verify part and application is correct before proceeding.
If missing part or damage item please customer service directly.**

**Call us at (909) 895-4522 Monday-Friday 9am-6pm PST
Email us at SUPPORT@ARMORDILLOUSA.COM**

ARMORDILLO RECOMMENDS PROFESSIONAL INSTALLATION ON ALL THEIR PRODUCTS

WARNING: When working on ,under or around vehicle exercise caution. If working without a lift check vehicle owners manual for correct jacking points. Always wear safety glasses and ensure a safe working area. Serious injury or death could occur if safety measures are not followed.

PERIODICALLY CHECK TO ENSURE ALL FASTENERS ARE TIGHT AND ALL STRUCTURAL COMPONENTS ARE SOUND CARE

To protect your investment, wax this product after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives, that could damage the finish.

For stainless steel: Aluminum polish may be used to polish small scratches and scuffs on the finish.
Mild soap may be used to clean bull guard.

For color finishes: Regular waxing is recommended to add a protective layer over the finish.
Mild soap may be used to clean the bull guard.

ARMORDILLO products are designed as decorative accessories and should not be relied upon as protection for the vehicle or passengers. Buyers assume all risk and liability whatsoever resulting from installation and use of ARMORDILLO products. ARMORDILLO assumes no liability for injury, loss, incidental or consequential damages in the event of an accident.

ARMORDILLO guarantees the original purchaser a LIMITED 1 YEAR WARRANTY from date of purchase against manufactured defects in materials, workmanship and finish under normal use. This excludes damage resulting from road hazards, debris, product misuse, improper installation, impairments from accidents, neglect, shipping or product modification. This warranty applies only to new products and is limited to the repair or replacement of ARMORDILLO products. Warranty does not included cost of removal, installation, labor, freight, inconvenience, or consequential damage. Original purchaser must return defective merchandise to the original place of purchase and must provide the proof of purchase. v

Bill Of Materials:



HARDWARE			
QTY	DESCRIPTION	QTY	DESCRIPTION
1	Bull Bar	4	M12 Lock Washer
2	Driver Bracket / Passenger Bracket	4	M12 Hex nut
4	M12-1.75 x 30mm Bolt	4	M12-1.25 x 30mm Bolt
4	M12 Washer		



TOOL REQUIRED



SIZE	DESCRIPTION
3/8"	Ratchet
10mm 18mm	Socket
3/4"	Wrench

LEVEL OF DIFFICULTY: **EASY**

PRO INSTALL TIME: **20 MIN.**

NOVICE INSTALL TIME: **40 MIN.**

INSTALLATION TIPS:

1) REMOVE CONTENTS FROM BOX, VERIFY ALL PARTS LISTED ARE PRESENT AND FREE OF DAMAGE. READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION.

2) CUTTING OF LOWER VALANCE OR TRIM MAYBE REQUIRE, INSTALLATION MAY INTERFERE WITH FRONT SENSORS ON BUMPER.

3) TWO PERSON WILL BE REQUIRED WHEN MOUNTING AND ALIGNING BULL BAR

4) USING PROPER TOOLS WILL IMPROVE THE QUALITY OF THE INSTALL AND REDUCE THE TIME REQUIRED.

5) NEED HELP OR HAVE SOME QUESTIONS CALL US AT (909) 895-4522 OR EMAIL US AT SUPPORT@ARMORDILLOUSA.COM

6) REMOVAL OF FRONT LICENSE PLATE IS REQUIRED, RELOCATION OF FRONT LICENSE PLATE IS HIGHLY RECOMMENDED.

7) ANTI-SEIZE LUBRICANT IS HIGHLY RECOMMEND TO USED ON ALL STAINLESS STEEL FASTENERS TO PREVENT DAMAGE TO THE THREAD AND GALLING.



Hardware Reference Chart

	M6	M8	M10	M12	M14	M16
Socket size	10mm	13mm	17mm	19mm	22mm	24mm
Grade 8.8/8.9	102ft.lbs.	20ft.lbs.	40ft.lbs.	70ft.lbs.	110ft.lbs.	175ft.lbs.
Grade 10.9	144ft.lbs.	30ft.lbs.	60ft.lbs.	140ft.lbs.	165ft.lbs.	225ft.lbs.

- 1) Remove lower air dam by removing six bolts from bottom of bumper. Save for later installation.
- 2) Determine passenger and driver brackets and install as shown. NOTE: If vehicle is equipped with optional tow hooks, they must be removed.
- 3) Temporarily attach Bull Bar to mount brackets as shown. Center and level.
- 4). Re-attach lower air dam and trim as necessary to fit around mount bracket and Bull Bar. It may be necessary to remove Bull Bar from brackets to fully attach lower air dam.
- 5). Re-attach Bull Bar to mount brackets using M12 serrated flange fasteners. Level and adjust Bull Bar as desired and tighten all fasteners.

