Warrior, Inc.
11100 SW Industrial Way
Tualatin, Oregon 97062
(503) 691-8915
(503) 692-0364 FAX
(888) 220-6861 Toll Free
wp@ warriorproducts.com

Warrior, Inc.

ADVENTURE RACK INSTALLATION INSTRUCTIONS WAR 833

- 1. Remove spare tire from the rear of the tailgate.
- 2. Remove the outer most bolt on the tailgate side of the hinge. (Both upper and lower) See figure "A"
- 3. Install passenger side leg over the tailgate hinge using the new longer bolts provided. Do not tighten the bolts at this time. (Bolt, lock washer, then flat washer)
- 4. on the latch side of the tailgate (see figure "A") drill 3/8" hole 1/2" from the side & 1/2" from the bottom of the tailgate.
- 5. Drill second 3/8" hole 1/2" from the side and 14 3/8" from the bottom of the tailgate. (see figure "A")
- 6. Install drivers side leg. Bolts are installed from inside of the tailgate pointing out. (see figure "B") Top bolt has a small flat washer next to bolt head (provided). Bottom bolt has large flat washer. Do not tighten bolts at this time.
- 7. Install basket on top of the legs.
- **8.** Install lower brackets to bottom of legs using quick release pins. Mark drilling holes on the vehicle body where the bracket is positioned.
- **9.** Remove brackets and drill 1/8" hole where marked. Install bracket using quick release pins before securing brackets with self tapping screws.
- **10.** Tighten all bolts and check to be sure the **Rack** is securely attached to the rear of the vehicle. If you have bolted the rack only to your tailgate, a 50lb. Weight limit is advised. ENJOY YOUR NEW RACK!

"Your Knight in Shining Armor!"