



Protecting Your Adventure Lifestyle

---

## **Aluminum Dash** **Installation Instructions**

**For YJ-WRANGLER, 1987 thru 1995**

**Part Number – 44399/90424**

**Part Number – B4399**

**Part Number – 44399PA**

### **Important:**

Carefully follow instructions for safe and proper usage of this product. The manufacturer and distributor of this product are in no way responsible for the customer's failure to adhere to the warnings and directions of these instructions, in the event of damage to the consumer's Jeep, or other properties and/or personal injury.

**Tools Needed:** Phillips head screw driver

**Box Contains:** 1-Dash and 12" of two-sided tape.

There is a total of 10 Phillips head screws holding the stock dash in place. Remove the 10 screws and hold your first piece, (which ever piece you choose, there is a total of three pieces) up against the stock dash to make sure it fits properly. If you decide to use the tape, make sure you clean the dash with some kind of cleaning solution so the two sided tape will stick on the dash. Put the double sided tape at the lower part of the dash. It should fit nice and snug and may not need the tape. Now reinstall the factory screws.