



TUBE DOORS

INSTALLATION INSTRUCTIONS

WAR 90771 / 90772 / 90773 / 90774
YJ & TJ WRANGLER & UNLIMITED
07 & UP JK

Read all instructions before proceeding.

NOTE: Fits all applications where hard door striker pins and rotary paddle latch are used. The doors are LEFT and RIGHT. The “WP” must be read from the outside of the Jeep facing the door. **EXAMPLE:** on drivers side the “WP” looks correct not backwards. The reason for this is the paddle handle mounting plate is offset to the inside.

1. Assemble the door paddle handle, both sides, with bolt and nuts supplied. Be sure to verify left and right sides, they are angled differently.
2. Hang door on jeep and check for proper fit. Close door slowly onto paddle striker being sure that the paddle and striker line up correctly.
4. Refer to diagram, included, to adjust the door up, if needed to center latch on the factory striker. You may also loosen the striker plate and adjust the plate up or down in or out for proper alignment

Enjoy your new Warrior tube doors!

“Your Knight in Shining Armor!”