



SIDE PANELS

DIAMOND PLATE / STEEL

All “SIDE PANELS” are designed to be placed over the existing metal surface. They fit between the fender wells with factory fenders and fender flares where applicable.

- 1) Be sure that the surface is flat before installing your side panels. Put some paint on any bare metal.
- 2) Lift one side panel up to the rocker panel and use it to determine where you want to place your mounting holes. Mark the mounting locations with a felt pen or other marker and remove for ease of drilling. If you are covering rust or damaged areas, try not to locate any mounting holes in these areas.
- 3) If using the “pop” rivets provided to attach your side panels, you will need to secure a drill, a 3/16” drill bit, and a “pop” rivet tool. Drill your mounting holes using the 3/16” drill bit.
- 4) Place your drilled side panel in location and mark through the holes onto the rocker panel. Drill mounting holes where indicated using your 3/16” bit. Be careful not to drill through anything that may be behind the rocker panel.
- 5) Install the side panels using the “pop” rivets supplied. If you prefer you can use self tapping bolts to install the panels.
- 6) Repeat the process described above for the other side.

CONGRATULATIONS! You have finished your installation. Enjoy your new Warrior Products Side Panels and be sure to look for other quality Warrior Products for your vehicle.

.....
“Your Knight in Shining Armor!”