



1-800-366-9712

INSTALLATION INSTRUCTIONS

2019 - up GMC 1500 GRILLE GUARD

PART # GGG19HBL1

***** FOR VEHICLES WITH SENSORS, YOU WILL NEED TO USE PSG19HBL1 *****

1. On models with tow hooks, loosen the 18mm bumper bolt, driver side only. This bolt is in the way of the tow hook bolt.



2. Remove the tow hook along with the plastic cover around it.



3. Also remove the tow hook trim panel. It is mounted by two 7mm screws and one clip.



- Slide the 5" tab w/the bolts through the top holes of the frame.



- From the back side, slide the mounting bracket through tow hook opening. Use 3/8" and 1/2" washers, lock washers and nuts to install.



- Reinstall the tow hooks. Use the factory tow hook bolts. If there are no tow hooks present, use 1/2" bolts. Also, at this time tighten the 18mm bolt that was loosened in step 1.



- Repeat steps 2-6 on the passenger side.



8. Install the grille guard by using the ½” carriage bolts, washers and lock nuts provided.
9. Level grille guard and tighten all bolts and nuts. You may have to loosen the mounting bracket bolts to help with leveling.

----- **WARNING** -----

Special care should be exercised in the handling, storage and installation of Ranch Hand equipment. The actual weight of each piece of equipment will vary depending on style and model. The weight of the equipment is sufficient in volume to warrant special care, assistance and in some instances, the use of mechanical equipment during the transfer and installation of the equipment. Do not assume a position directly under the equipment during installation. Be sure the equipment has been connected and stabilized during installation to prevent falling or shifting of positions. Periodically check tightness of bolts to make sure they are tight, and unlikely to fail.