

# INSTALLATION MANUAL

## Level of Difficulty

Easy

Installation difficulty levels are based on time and effort involved and may vary depending on the installer level of expertise, condition of the vehicle and proper tools and equipment.

## Parts List

Qty	Description
1	Driver / left running board
1	Passenger / right running board
16	Hex bolt, M8
16	Flat washer, M8
16	Lock washer, M8

## Tools Required

Wrench, 12mm	Wrench, 13mm
--------------	--------------

## Torque Specifications

M8 bolt	15 ft.-lbs.
---------	-------------

Use above torque setting unless otherwise noted

## Product Photo



## NOTICE

Visit [www.ranchhand.com](http://www.ranchhand.com) for a full-color copy of this instruction manual, as well as helpful videos, guides and much more!

Before you begin installation, read all instructions thoroughly.

Proper tools will improve the quality of installation and reduce the time required.

Periodic inspection of your product should be performed to ensure all hardware and / or components remain secure.

To help prevent damage to the product or vehicle, refer to the specified torque specifications when securing hardware during the installation process.

## Maintenance

Mild automotive detergent may be used to clean the product. Do not use dish detergent, abrasive cleaners, abrasive pads, wire brushes or other similar products that may damage the finish.

## Product Registration and Warranty

Ranch Hand stands behind our products with industry-leading warranties. To get copies of the product warranties, register your purchase or provide feedback, visit: [warranty.curtgroup.com/surveys](http://warranty.curtgroup.com/surveys)

### Step 1

Remove factory running boards and hardware (if applicable).

---

### Step 2

Position the running board on the side of the vehicle. The larger step goes towards the front of the vehicle. Test fit the running step to the factory bolt hole locations.

**Note:** The step should line up with the existing factory bolt locations.



### Step 3

Starting with one of the center brackets, insert an M8 hex bolt, lock washer and flat washer into the factory bolt locations and hand tighten.

Loosely install all of the remaining M8 hex bolts, lock washers and flat washers.

Torque each bolt location to 15 ft-lbs.

---

### Step 4

Repeat steps 1 through 3 on the passenger side of the vehicle.

To protect your investment, see the 'Notes and Maintenance' section on page one.

Congratulations on the installation of your new Ranch Hand™ running steps.

---