

REAR SHOCK SKIDS

10-23 TOYOTA 4RUNNER

SPTF3-01



TOOLS REQUIRED

- 17, 18mm Socket
- 19mm Wrench
- Thread Locker

SKILL LEVEL

- Novice/Intermediate
- 1 (you)

Little skill level required, you can easily install it by yourself however, additional help will be useful

TIME REQUIRED

- 1 Hour

Time to install this should only take about one hour

WARNINGS/CAUTIONS BEFORE STARTING INSTALLATION

Before you install this kit – Read and understand all instructions, warnings, cautions, and notes contained in this installation instruction guide. Consult your vehicle owner's manual for proper disconnection of electrical and lifting of vehicle if required for installation of this product.

This install may require some technical skills and knowledge of basic mechanical work. If you do not feel that you are capable of performing this install please take this product to a trained professional.

After reading this guide please contact us with any questions or concerns before installing product.
Customer Service: 855-680-9595

DV8 Offroad is not responsible for any bodily injury or harm to you or your vehicle as a result of an improper install.



INSTALLATION MANUAL

Begin by unpacking all items and inspecting for missing pieces or damage. If you have any concerns, please contact the company the product was purchased from. Extra hardware may be included with the product.

HARDWARE INCLUDED

- (2) M12x110 Hex
- (2) M12 Flat Washer
- (2) M12 Nylon Lock Nut



STEP 2 | Use an 18mm socket to remove the factory bolt securing the strut in place.



STEP 1 | Slide the skid plate over the lower strut mount, and loosely secure the factory shock bolt and the provided M8 hardware.

Recommended: Use a small amount of thread locker on this bolt.



INSTALLATION MANUAL

STEP 3 | Torque the factory bolt to 72 ft-lbs using a 18mm socket.



STEP 4 | Use a 17mm socket and 19mm wrench to secure the provided M10 hardware.

Repeat steps for opposite side of the vehicle.



STEP 5 | Double check fitment and all hardware is secure.

Congratulations! You are finished with the install of the 10+ Toyota 4Runner Shock Skids.

