

## SHOCK MOUNT SKID

2016-2023 TOYOTA TACOMA

SPTT1-02



### TOOLS REQUIRED

- 17mm, 18mm sockets
- 17mm, 18mm, 19mm wrenches
- Safety Glasses

### SKILL LEVEL

- Novice/Intermediate
- 1 (you) to 2 persons

Little skill level required, you can easily install it by yourself however, additional help will be useful

### TIME REQUIRED

- 1.5 Hour

Time to install this should only take about an hour and a half.

## WARNINGS/CAUTIONS BEFORE STARTING INSTALLATION

Before you install this kit – Read and understand all instructions, warnings, cautions, and notes contained in this installation instruction guide. Consult your vehicle owner’s manual for proper disconnection of electrical and lifting of vehicle if required for installation of this product.

This install may require some technical skills and knowledge of basic mechanical work. If you do not feel that you are capable of performing this install please take this product to a trained professional.

After reading this guide please contact us with any questions or concerns before installing product.  
Customer Service: 855-680-9595

*DV8 Offroad is not responsible for any bodily injury or harm to you or your vehicle as a result of an improper install.*

Proper installation of this kit required knowledge of the factory recommended procedures for removal and installation of original equipment components. We recommend that the factory shop manual and any special tools needed to service your vehicle be on hand during the installation. Installation of this kit without proper knowledge of the factory recommended procedures may affect the performance of these components and the safety of the vehicle

- Always wear eye protection when operating power tools

*Inspect all contents of this package to make sure product is not damaged and all installation hardware has been included. If parts are missing from kit, please be prepared to provide the following information*

1. Name of purchase location
2. Bar Code on side of box
3. Date above bar code
4. Date inside box cover



# INSTALLATION MANUAL

Begin by unpacking all items and inspecting for missing pieces or damage. If you have any concerns, please contact the company the product was purchased from. Extra hardware may be included with the product.

## HARDWARE INCLUDED

- (2) M12x75mm Bolts
- (2) M12x85mm Bolts
- (4) M12 Lock Nuts
- (8) M12 Washers



**STEP 1** | If installing the skid plate with the vehicle on a lift, support the side of the axle you are working on with an underhoist support.



**STEP 2** | Use a 19mm socket to remove the (4) leaf spring U-bolt nuts.

Remove the U bolt bottom plate and set it off to the side.



# INSTALLATION **MANUAL**

---

**STEP 3** | Use a 17mm wrench and socket to remove the shock to axle mounting bolt.





# INSTALLATION MANUAL

**STEP 4 |** Install the DV8 Shock Mount Skid, use the provided M12 hardware, an 18mm socket and a 19mm wrench.

The shorter M12x75mm bolt provided will replace the factory shock axle mount bolt.

The longer bolt will be used at the top hole.



**STEP 5 |** Torque both M12 bolts to 93ft lbs.



# INSTALLATION MANUAL

**STEP 6 |** Reinstall the U-bolt bottom plate using the factory hardware and a 19mm socket.

Torque U-bolt factory hardware to factory specs.



**STEP 7 |** Double check that all hardware is torqued to spec.

Congratulations, installation of the Tacoma Shock Mount Skids!

