

UPPER REAR BODY ARMOR



1. REMOVE INNER DRIVER SIDE AND PASSENGER SIDE PANEL WITH PHILLIPS HEAD SCREWS.
2. REMOVE REAR SEAT LATCH.



3. REMOVE SEAT BELT REEL MOUNT.



4. REMOVE VENT IN DOOR JAMB WITH T15 TORX TO GAIN ACCESS TO LOWER BOLT.



RIVNUTS IN THESE HOLES

5. HOLD PANEL IN PLACE AND MARK HOLES WITH MARKER.
6. DRILL HOLES - 3/8" HOLES FOR BOLTS AND 7/16" HOLES FOR RIVNUTS.
7. INSTALL RIVNUTS PER SPEC. IN LOCATIONS SHOWN.
8. BOLT USING 5/16-18 X 1" LONG BHSCS AND SERRATED NUTS.
9. REPEAT FOR OPPOSITE SIDE