

800050 & 800060 Series Leaf Spring Shims INSTALLATION INSTRUCTIONS

NOTE: Leaf spring shims should be installed by someone with a strong aptitude in leaf spring suspension. If you are unsure on how to use and install these shims, it is best if you refer to a professional.



- 1. These shims are designed to bolt into the leaf pack through the cross pin in the springs.
- 2. If your cross pin is not long enough to fit through the shim, you will need to get a longer pin
- 3. Cross-pin size is 5/16". If you have a larger pin size, you will need to drill out the shim.

QUALITY • INTEGRITY • INNOVATION • SERVICE