

## TACOMA CENTER CONSOLE AND BRIDGE

2016-2023 (3RD GEN) TOYOTA TACOMA  
CCT1-01



### TOOLS REQUIRED

- 10mm wrench
- #4 Allen Bit
- Trim tool (optional)
- 11/32" Drill Bit
- Drill

### SKILL LEVEL

- Novice/Intermediate
  - 1 (you) to 2 persons
- Little skill level required, you can easily install it by yourself however, additional help will be useful

### TIME REQUIRED

- 1 Hour
- Time to install this should only take about an hour

## WARNINGS/CAUTIONS BEFORE STARTING INSTALLATION

Before you install this kit – Read and understand all instructions, warnings, cautions, and notes contained in this installation instruction guide. Consult your vehicle owner's manual for proper disconnection of electrical and lifting of vehicle if required for installation of this product.

This install may require some technical skills and knowledge of basic mechanical work. If you do not feel that you are capable of performing this install please take this product to a trained professional.

After reading this guide please contact us with any questions or concerns before installing product.  
Customer Service: 855-680-9595

*DV8 Offroad is not responsible for any bodily injury or harm to you or your vehicle as a result of an improper install.*

Proper installation of this kit required knowledge of the factory recommended procedures for removal and installation of original equipment components. We recommend that the factory shop manual and any special tools needed to service your vehicle be on hand during the installation. Installation of this kit without proper knowledge of the factory recommended procedures may affect the performance of these components and the safety of the vehicle

- Always wear eye protection when operating power tools

*Inspect all contents of this package to make sure product is not damaged and all installation hardware has been included. If parts are missing from kit, please be prepared to provide the following information*

1. Name of purchase location
2. Bar Code on side of box
3. Date above bar code
4. Date inside box cover



# INSTALLATION MANUAL

Begin by unpacking all items and inspecting for missing pieces or damage. If you have any concerns, please contact the company the product was purchased from.

## HARDWARE INCLUDED

- (10) M6x15mm Bolts
- (10) M6 Flat Washers
- (6) M6 Nuts



**STEP 1** | Line the side brackets up against the center console of the vehicle. You will want to focus on the top edge of the bracket with the trim line of the vehicle. Using a marker or punch, mark the mounting holes of the side brackets.

The bottom of the panel should be resting against the carpet of the vehicle.

*Tip: This can be done with both sides and the bridge assembled together, or separately.*



**STEP 2** | Once all holes are marked, using a 11/32" drill bit, drill the holes only cutting through the plastic of the center console.




## INSTALLATION MANUAL

**STEP 3** | Once all holes are drilled, push down on the chrome bezel just below the shifter to release the boot. Unscrew the shifter and set off to the side.



**STEP 4** | Gripping the top of the center console, pull up to release the clips until the center console is free.

*Note: Do not pull up all the way since there is an electrical connection near the shifter.*





# INSTALLATION MANUAL

**STEP 5 |** Secure side mounts using the provided M6 hardware with a 4mm allen bit. Apply pressure to the nut with your hand until it “catches” and is secure. Ensure they stay aligned with the trim on the center console.

Use a 10mm wrench if necessary.



**STEP 6 |** Once panels are installed, push center back down into place and ensure clips are secure. Reinstall shifter knob and boot.



# INSTALLATION MANUAL

**STEP 7** | Using the remaining M6 hardware and #4 allen bit, install the bridge. Align with dash and ensure it is level.



**STEP 8** | Double check all hardware is secure. Congratulations, you are done with your new Tacoma Center Console and Bridge!

